



DIRECT+ Conditioning System



ENVOY



AUTHORITY22

Select Machine

Pattern Information

Date: 2-syys-22
Pattern Type:
Pattern Difficulty:
Pattern Designer: jkl
Pattern Volume (ml): 19,00

Surface Information

Surface Type: Synthetic
Surface Brand:
Age:

Pattern Parameters

Pattern Number:
Pattern Name: Syyskisa 2022
Mode: Clean & Oil
Forward Speed: Quick Clean
Start Cleaner Spray: 0
Start Squeegee: 0
Start Oiling: 6
Split Pattern:


Supplies Information

Lane Cleaner: Judge
Cleaner Mixture Ratio: 6 : 1
Cleaner Transition Distance: Authority22
Cleaner Spray End Distance: 54 Envoy
Lane Conditioner: Logic

Notes:

Table with 8 columns (Zone 1-8) and 3 rows (Zone End Distance, Zone Ratio, Zone Volume (ml)).

Table with 8 rows (ZONE 1-8) and 34 columns (7 Pin Side, Board Number, 10 Pin Side).





Syyskisa 2022

Crosswise Ratios (by units)

| Zone 1 | | | Zone 5 | | |
|---------|---------------|-------|---------|-------------------|----------|
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 34,0 | 2,5 | 3L-7L | Left = 0,0 | #JAKO/0! |
| 3R-7R | Right= 34,0 | 2,5 | 3R-7R | Right= 0,0 | #JAKO/0! |
| 18L-18R | Center = 85,0 | | 18L-18R | Center= 0,0 | |
| Zone 2 | | | Zone 6 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 20,8 | 2,6 | 3L-7L | Left = #JAKO/0! | #JAKO/0! |
| 3R-7R | Right= 20,8 | 2,6 | 3R-7R | Right= #JAKO/0! | #JAKO/0! |
| 18L-18R | Center= 55,0 | | 18L-18R | Center= #JAKO/0! | |
| Zone 3 | | | Zone 7 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 8,0 | 5,0 | 3L-7L | Left = #JAKO/0! | #JAKO/0! |
| 3R-7R | Right= 8,0 | 5,0 | 3R-7R | Right= #JAKO/0! | #JAKO/0! |
| 18L-18R | Center= 40,0 | | 18L-18R | Center = #JAKO/0! | |
| Zone 4 | | | Zone 8 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 4,2 | 5,9 | 3L-7L | Left = #JAKO/0! | #JAKO/0! |
| 3R-7R | Right= 4,2 | 5,9 | 3R-7R | Right= #JAKO/0! | #JAKO/0! |
| 18L-18R | Center = 25,0 | | 18L-18R | Center= #JAKO/0! | |

Crosswise Ratios (by ml)

| Zone 1 | | | Zone 5 | | |
|---------|----------------|-------|---------|----------------|----------|
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 0,114 | 2,5 | 3L-7L | Left = 0,000 | #JAKO/0! |
| 3R-7R | Right= 0,114 | 2,5 | 3R-7R | Right= 0,000 | #JAKO/0! |
| 18L-18R | Center = 0,285 | | 18L-18R | Center= 0,000 | |
| Zone 2 | | | Zone 6 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 0,078 | 2,6 | 3L-7L | Left = 0,000 | #JAKO/0! |
| 3R-7R | Right= 0,078 | 2,6 | 3R-7R | Right= 0,000 | #JAKO/0! |
| 18L-18R | Center= 0,207 | | 18L-18R | Center= 0,000 | |
| Zone 3 | | | Zone 7 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 0,030 | 5,0 | 3L-7L | Left = 0,000 | #JAKO/0! |
| 3R-7R | Right= 0,030 | 5,0 | 3R-7R | Right= 0,000 | #JAKO/0! |
| 18L-18R | Center= 0,151 | | 18L-18R | Center = 0,000 | |
| Zone 4 | | | Zone 8 | | |
| | Average | Ratio | | Average | Ratio |
| 3L-7L | Left = 0,011 | 5,9 | 3L-7L | Left = 0,000 | #JAKO/0! |
| 3R-7R | Right= 0,011 | 5,9 | 3R-7R | Right= 0,000 | #JAKO/0! |
| 18L-18R | Center = 0,063 | | 18L-18R | Center= 0,000 | |

The crosswise ratios are calculated by the average units of oil for boards 18L - 18R and divided by the average units of oil for board 3 - 7 left and right.

